

Document Title: Description, LIT, App Note, DataTrac on Vista		Part # and Rev. 13470	
		Release Date:	
Rev.	Description	Revision By	Date

Production Filename: 13470 (In Product Library)

Path to Working Files: DecaDoc\Application Notes\Master

Dimensions: 8.5 inch wide, 11 inch tall

Material: Paper, 92 Bright White or better, 75g/m² or heavier

Colors: Color Print on White

Printer: HP Color LaserJet 8550-PS

Finish: None

Adhesive: None

Special Notes: Illustrations are Ref Only ** Not to Scale **


Application Note

Using ECHO DataTrac on a computer with Microsoft Windows Vista

Microsoft designed their new Windows Vista operating system to be more secure and less susceptible to viruses. Some of these new features prevent DataTrac from writing data to your computer. This document explains how to install and configure DataTrac to run on one Windows Vista.

To install and use DataTrac, you need a user account with "Administrative" privileges. For most home and small business users, your account should have administrator privileges. If you do not have a user account with administrative privileges, please contact your favorite computer support person for help.

1. Copy the DataTrac installer to your desktop.
Copy the DataTrac installer from the install CD. From the install CD menu window, click the "Explore this CD" icon. This opens a window showing the contents of the install CD. Click and drag the DataTrac installer to your desktop (you need the full article, not the "ECHO"). Look for the file named "ECHO_DataTrac_2.70_Setup".

You may also download the latest version of DataTrac from Decagon's web site (<http://www.decagon.com/ask/so/softwre>). Click on the link that download the full install version of DataTrac.

2. Run the installer in Windows XP compatibility mode.
A. Right-click on the DataTrac installer file named "ECHO_DataTrac_2.70_Setup".
B. Choose "Properties" from the menu. This opens the properties window.
C. Click on the "Compatibility" tab at the top of the window.
D. Click on the "Run this program in compatibility mode for" checkbox.
E. Select "Windows XP (Service pack 2)" from the combo box.
F. Click on the "Run this program as an administrator" checkbox.

G. Click the "OK" button to dismiss the properties window.
Please note: In this step, you are not asked to restart your computer.
H. Double-click the installer file to launch the DataTrac setup program.
I. Click "Continue" when Vista asks you to confirm you want to launch the installer.
J. Continue DataTrac installation.
K. When the installation is finished, you can drag the installer file to the Recycle Bin.

3. Configure DataTrac to run in Windows XP compatibility mode.
A. Click the "Start" button. Choose "All Programs" and "ECHO DataTrac".
B. Right-click on the "ECHO DataTrac" program icon.
C. Choose "Properties" from the menu. This opens the properties window.
D. Click on the "Compatibility" tab at the top of the window.
E. Click on the "Run this program as an administrator" checkbox.
F. Click the "OK" button to dismiss the properties window.
G. DataTrac is now ready to use in Windows Vista.

PLEASE NOTE: Each time you launch DataTrac, Windows Vista will ask you to click "Continue" to allow the data to use DataTrac.

Troubleshooting
If DataTrac gives you an error "DataTrac CANNOT load the Device Driver", follow the steps in section 3 above. DataTrac must have permissions to write to the Program Files directory where it is installed.
If you have further questions about running DataTrac on Windows Vista, please contact your Decagon representative or contact Decagon directly at etm@decagon.com.

13470-00 © 2007 Decagon Devices, Inc. All rights reserved
www.decagon.com
support@decagon.com