

Document Title: Description, Ech2o Check User's Guide Card		Part # 10688	
		Release Date: 03/14/07	
Rev.	Description	Revision By	Date
05	Made smaller and remove items to fit in new carrying case	Laura	3/14/07
06	Added 10HS to usable sensors	Derek	06/04/09

Production Filename: 10688-06 Ech2o Check User's Guide Card.pdf

Dimensions: 2.375 inch wide, 3.50 inch tall
Corners are to be rounded .25"

Text Color: Black

Material: Green Card Stock

Finish: Hard Laminated (no overhang)

Adhesive: None

Special Notes: Pages are duplexed front to Back. Illustrations are for Ref Only
**Not to scale **

Front

ECH₂O Check Quick Start Guide

- **Select your probe type:**
Press and hold the left (I) button, then press the right (II) button repeatedly to cycle through types:
ES is for the EC-5 probe
10H is for the 10HS probe
E 10 is for the EC-10 probe
E20 is for the EC-20 probe
USR is for user-set calibration
- **Press the right (II) button to scroll through display modes:**
*Pct: percent water content (cm/m)
*IPF: inches per foot (water content)
Analog/digital converter value

Back

- **To make a measurement:**
Press the left (I) button

**Note: If probe is measured in air while in "IPF" or "PCT" mode, a negative value will be displayed.*
- To adjust calibration, refer to the operations guide.
- To replace the battery, unscrew the back of case. Battery size: CR2
- The ECH₂O Check will shut off automatically when not in use for more than 5 minutes.

© 2009 Decagon Devices, Inc.

10688-06

Illustrations are for Ref Only

**Not to scale **